VIBRATOR TOYJOY GET REAL

User manual

CONTROL
1) Unscrew the bottom cover and insert the batteries according to the poles.
2) Screw the cap back on and briefly press the button on the base.
3) The first vibration mode starts and subsequent short button presses change the modes.
4) To turn off, hold the button for 3 seconds.

MAINTENANCE
After each use, rinse the vibrator with lukewarm water and soapy detergent.
You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.
Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF
The vibrator is **water resistant**, so maintenance is very easy.
Water resistant means that splashing water will fall on it, but you **MUST NOT submerge it in water!**
You could only immerse the product in water if it was **waterproof**.

LUBRICATION
Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING
The vibrator is powered by two AA batteries. For greater endurance, we recommend using alkaline or rechargeable batteries.

STORAGE
Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS
Vibrator.

Růžový slon s. r. o.
Výstavní 1928/9
722 00 Ostrava – Moravská Ostrava, Czech Republic

Potřebujete poradit?
Napište nám na ahoj@flagranti.cz
nebo zavolejte na 555 333 169