

# PENIS RING PRIMEROS VIBRATING



## User manual

### CONTROL

- 1) Briefly press the button on the tip of the ring to start the vibration.
- 2) Briefly press the button on the tip of the ring to turn off the vibration.

### MAINTENANCE

After each use, remove the cartridge from the ring and rinse with lukewarm water and soap. You can also use a **sex toys cleaner**, which additionally helps to remove microscopic dirt. Just spray the product, let it work for about 1 minute and then dry it with a lint-free towel or cloth.

### WATER RESISTANCE

The vibrating ring is not waterproof or waterproof. Therefore, if you want to clean it, you always need to remove the vibrating cartridge!

### LUBRICATION

Use only **WATER BASED lubricants**. Other lubricating gels could damage the surface of the device and it would then become sticky.

### PROPULSION AND CHARGING

The vibrating ring is powered by a single use battery.

### STORAGE

Store separately from other erotic aids in a dry and dark place.

### PACKAGE CONTENTS

The package includes a vibrating ring.