

DREAM TOYS GLAM STRONG ANAL

User manual



CONTROL

- 1) Turn on the vibrator by pressing the button on the base for about 3 seconds. You will put it into standby mode. It will welcome you with a lighting of the LED diode and a short vibration.
- 2) With subsequent short presses of the same button, you can turn on and change the individual vibration and pulsation rhythms.
- 3) Press the button for about 3 seconds to turn off the vibrator.
- 4) For use with the remote control, turn the vibrator into standby mode.
- 5) With subsequent short presses of the lower "power" button on the remote control, you can turn the vibrations on and off.
- 6) With short presses of the upper button with the "wave" symbol, you can switch between the individual rhythms.
- 7) To completely turn off the vibrator, you must always turn it off with its own button.

MAINTENANCE

After each use, rinse the product with lukewarm water.

We also recommend using an **erotic cleaner**, which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The product is **water resistant**, so maintenance is very easy.

The product can be splashed with water, but you **MUST NOT immerse it in water!**

Waterproof means that you could completely submerge the product in water and enjoy water play.

Due only to the water resistance of the product, this is not possible in this case.

LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The product is powered by an integrated battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently. Charging time is about 120 minutes. The remote control is also powered by an integrated battery and can be charged with the included USB-C cable.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

The package includes a vibrator, a remote control, a magnetic USB cable and a USB-C cable for charging.