

VIBRATING EGG EASYTOYS WITH REMOTE CONTROL

User manual



CONTROL

- 1) Hold the power button on the egg for 2 seconds to turn on. The egg will welcome you by lighting up the LEDs.
- 2) Subsequent short presses turn it on and change the vibration and pulsation modes.
- 3) Turn it off by long pressing the power button again for 2 seconds.
- 4) If you want to control the egg with the remote control, you must always first switch on the device itself by long pressing the power button.
- 5) Afterwards, the middle button on the controller is used to switch the egg on and off by pressing it briefly.
- 6) The + and - buttons are used to select the speed, the buttons with the wave symbol are used to select the degree of pulsation.

MAINTENANCE

After each use, rinse the product with lukewarm water.

We also recommend using an **erotic cleaner**, which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The product is **water resistant**, so maintenance is very easy.

The product can be splashed with water, but you **MUST NOT immerse it in water!**

Waterproof means that you could completely submerge the product in water and enjoy water play.

Due only to the water resistance of the product, this is not possible in this case.

LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The product is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently.

The remote control is powered by CR2032 battery.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find a vibrator, remote control, USB cable for charging, CR2032 battery.