

FAIRYGASM HEARTGEM STIMULATOR

User manual



CONTROL

- 1) Hold the heart button on the body of the stimulator for 3 seconds to switch it on standby mode. A short vibration greets you and the LED lights up.
- 2) Additional short presses turn on and change the individual vibration and pulsation rhythms.
- 3) Switch it off again by holding the button for 3 seconds.
- 4) For use with the remote control, switch the stimulator to standby mode.
- 5) Now briefly press the button on the remote with the wave symbol to switch on and change the individual vibration and pulsation rhythms.
- 6) Press the button with the pause symbol briefly to pause the vibrations.
- 7) Do not switch the controller on or off in any way, you must then switch the stimulator off with its own button.

MAINTENANCE

After each use, rinse the product with lukewarm water and soapy detergent.

You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The product is **water resistant**, so maintenance is very easy.

The product can be splashed with water, but you **MUST NOT immerse it in water!**

Waterproof means that you could completely submerge the product in water and enjoy water play.

Due only to the water resistance of the product, this is not possible in this case.

The remote is not **waterproof or water resistant!**

LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The product is powered by an integrated Li-on battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently.

The remote control is also powered by an internal battery.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find a stimulator, remote control and USB cable for charging.