

FETISH FANTASY INTERNATIONAL ROCKIN' CHAIR



User manual

CONTROL

- 1) Plug the controller into the bottom hole of the chair and plug the AC adapter into the controller and plug it into a power outlet.
- 2) Press the power button briefly to immediately start the vibration.
- 3) Use the + and - buttons to change the vibration intensity.
- 4) Press the power button again to switch the chair off.
- 5) The controller has an LED indicator that shows you the current vibration intensity.

MAINTENANCE

After each use, rinse the chair with lukewarm water and soapy detergent.

You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The chair is **not water resistant or waterproof!**

LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The chair is powered from mains electricity.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

In the package you will find a clitoral stimulator chair, remote control, power adapter, eye mask, lubricating gel and cleaner.