

# PRETTY LOVE SLOANE PENIS SLEEVE



## User manual

### CONTROL

- 1) The bottom of the vibrating cartridge serves as a cover for the batteries.
- 2) Unscrew it and insert three LR936 batteries into the vibrating cartridge according to the marked poles.
- 3) Screw them back in.
- 4) There is a wheel on the cover that is also used for on/off and infinitely variable vibration control.

### MAINTENANCE

After each use, rinse the device with lukewarm water and soapy detergent.

You can also use an [erotic cleaner](#), which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

### WATERPROOF

The cartridge is **not waterproof or water resistant!** The penis sleeve is **fully waterproof.**

### LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

### DRIVE AND CHARGING

The vibrating cartridge is powered by three LR936 batteries.

### STORAGE

Store separately from other erotic aids in a dry and dark place.

### PACKAGING CONTENTS

In the package you will find a penis sleeve, a vibrating cartridge and 3 LR936 batteries.