

STRAP-ON-ME MULTI ORGASM BENDABLE STRAP-ON VIBRATOR



User manual

CONTROL

- 1) Turn the vibrator on and off by pressing the side button "power" for about 3 seconds. The LED diode lights up and it is put into standby mode.
- 2) With subsequent short presses of this button, you turn on and change the individual vibration rhythms.
- 3) Turn the remote control on and off by pressing the "power" button for about 3 seconds.
- 4) The button with the highlighted "tip" symbol is used to switch the vibration modes in the tip of the vibrator.
- 5) The button with the highlighted "center part" symbol is used to control the clitoral pressure stimulator.
- 6) The button with the highlighted "egg" symbol is used to switch the vibration modes of the vibrating egg for G-spot stimulation.
- 7) The "+" and "-" buttons are used to increase or decrease the intensity in the relevant parts of the vibrator.

MAINTENANCE

After each use, rinse the product with lukewarm water. We also recommend using an [erotic cleaner](#), which also helps to remove microscopic dirt. Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The product is fully **waterproof**, so maintenance is very easy. It may get splashed with water, but you can safely immerse it in water and enjoy water play.

LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The product is powered by an integrated battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently. Charging time is about 120 minutes.

The remote control is powered by CR2032 battery.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

The package includes a vibrator, a remote control, a magnetic USB charging cable and a CR2032 battery.