

YOU2TOYS RC FUCKING MACHINE WITH REMOTE CONTROL

User manual



CONTROL

- 1) Activate and deactivate the travel lock by pressing the lower “power” button for about 3 seconds, which is confirmed by a double flash of the LEDs.
- 2) Briefly press the “power” button to switch the vibrator to standby mode.
- 3) By successively short pressing the middle button with the “wave” symbol, you switch on and change the individual vibration and pulsation rhythms.
- 4) By pressing the button for about 3 seconds, you pause the vibrations.
- 5) By briefly pressing the upper button with the “arrow” symbol, you switch on and change the individual thrusting speeds.
- 6) By pressing the button for about 3 seconds, you pause the thrusting.
- 7) Briefly press the “power” button to switch it off.

For use with the remote control, switch the vibrator to standby mode.

- 8) Activate and deactivate the travel lock of the controller by holding the lower “power” button for approx. 3 seconds, which is confirmed by a double flash of the LED.
- 9) Briefly press the “power” button to turn on the controller and the LED will light up.
- 10) By successively short pressing the middle button with the “wave” symbol, you turn on and change the individual vibration and pulsation rhythms.
- 11) By pressing the button for approx. 3 seconds, you pause the vibrations.
- 12) By briefly pressing the upper button with the “arrow” symbol, you turn on and change the individual thrusting speeds.
- 13) By pressing the button for approx. 3 seconds, you pause thrusting.
- 14) By briefly pressing the “power” button, you turn off the controller and vibrator.

MAINTENANCE

After each use, rinse the product with lukewarm water.

We also recommend using an [erotic cleaner](#), which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The product is **not water resistant or waterproof!**

LUBRICATION

Use only [water-based lubricants](#). Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The product is powered by an integrated battery, which is approximately half charged from the factory, but we recommend that you fully charge it before first use.

Charge the battery using the included USB cable, which can be plugged into a phone adapter, PC or powerbank. When charging, the LED flashes and when fully charged, the LED control lights up permanently. The package includes a vibrator, a remote control, a vibrator suction cup and a USB charging cable.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

The package includes a vibrator, a remote control, a vibrator suction cup and a USB charging cable.