

SADA STA HARD ERECTOR SET

User manual



PUMP CONTROL

- 1) Insert the penis through the cuff into the top hat and start squeezing the suction balloon. The balloon, by its expansion, creates a vacuum and your penis becomes engorged and swollen - then it is ready for immediate action.
- 2) To release, let air into the vacuum pump by squeezing the safety catch under the balloon.

VIBRATING EGG CONTROL

- 1) Insert two AA batteries into the remote control according to the marked poles.
- 2) To control the vibration, turn the wheel on the side of the remote control.

MAINTENANCE

Rinse the tools with lukewarm water and soapy detergent after each use.

You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.

Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The egg is **not waterproof or water resistant!**

LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The egg is powered by two AA batteries. For greater endurance, we recommend using alkaline or rechargeable batteries.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

Vacuum pump, vibrating egg with remote control, double erection ring and penis cuff or vibrator.